



NOTES:

- A. VISIT WWW.SHARKSKINROOF.COM TO REVIEW THE COMPLETE LINE OF ROOF UNDERLAYMENTS, APPLICATIONS AND INSTALLATION INSTRUCTIONS
- B. CLEAN MASONRY AND WIPE DOWN WITH WET SPONGE PRIOR TO INSTALLATION OF SHARKSKIN ULTRA SA
- C. INSTALL SHARKSKIN ULTRA SA IN ORDER AS SHOWN BY NUMBERS
- D. APPLY A BEAD OF CAULKING/SEALANT ALONG THE TOP EDGE OF SHARKSKIN ULTRA SA ON CHIMNEY
- E. INSTALL SHARKSKIN ULTRA SA TO FORM WATER SHEDDING LAPS
- F. INSTALL PROPER METAL COUNTER-FLASHING PER LOCAL CODES