

## NOTES:

- A. VISIT WWW.SHARKSKINROOF.COM TO REVIEW THE COMPLETE LINE OF ROOF UNDERLAYMENTS, APPLICATIONS AND INSTALLATION INSTRUCTIONS
- B. REMOVE RELEASE LINER AT TIME OF INSTALLATION OF CORNER APTCH
- C. NOMINAL PATCH SIZE IS 6" X 6"
- C. FOR SEVERE WEATHER CLIMATES, PATCH SIZE IS 12" X 12"



CORNER DETAILING PATCH OPTIONS

SHARKSKIN ULTRA SA® - ALL WEATHER BARRIER

Drawing: SSUSA - 11

Scale: Not to Scale

Created: 02/24/2019

Supersedes: 07/23/2014