



May 11, 2020

Re: Sharkskin Ultra SA® - Installations on vertical surfaces as a waterproofing membrane

1. Sharkskin Ultra SA can be installed on vertical wall surfaces as a water proofing membrane when installed per installation instructions.
2. No primer is required over concrete, CMU block, Densdeck, Metal, TPO, EPDM, Plywood, OSB or Polyiso.
3. Installation instructions are on each roll label.
4. Sharkskin Ultra SA® is considered an air and vapor barrier.
5. Local building codes and building envelope science should be followed.

**Technical Department**

**Kirsch Building Products LLC**

**Tel: (805) 750-0084**

**Fax: (805) 526-1116**

**1464 Madera Road #N, Suite 387 • Simi Valley, CA 93065**

**email: [kirsch@sharkskin.us](mailto:kirsch@sharkskin.us) • [www.sharkskin.us](http://www.sharkskin.us)**