



Sharkskin Ultra SA® is the state of the art in self-adhered high temp resistant polymeric roof underlayments for “All Weather Protection”, including ice dam, hurricane, tornado, and hail.

Sharkskin Ultra SA® - Out Performs the competition!

1. Color: Cool Gray
2. Faster Installation: 48" x 125' rolls increase installation time and meet most ice barrier codes with one course.
3. High temperature resistance: up to 280°F, both the engineered polypropylene composite substrate and synthetic rubber adhesive.
4. Low temp installation: 20°F and rising
5. UV Exposure: up to 12 months. Zenon Arc testing per Miami-Dade TAS 103
6. Superior adhesion: out performs the adhesion of SBS Modified Asphalt based roof underlayments. 6.1 lbs/in.
7. No primer required: concrete, metal, OSB, Plywood, Densdeck, and Polyiso
8. No mastic: no mastic required on vertical end laps and at hips.
9. Seals around nails and screws: 100% solids, no fillers like asphalt-based roof underlayments
10. Slip-Resistant: Even when wet!
11. Split release liner: silicone release coated on both sides, liner will not stick to adhesive
12. Adhesive set clay/concrete tile systems: ICP Polyset, Dow and DAP 1 & 2 component tested
13. Code Compliance: ICC-ES AC48, Florida Building Code, Miami-Dade TAS 103 and Texas Department of Insurance

Sharkskin Ultra SA® Installation Instructions:

- Install Sharkskin Ultra SA® when the air, roof deck, and roof underlayment are at a minimum 20°F and rising.
- Position and cut roll to length as desired and pull release liner to install. Test small sample roll as adhesive is aggressive.
- Roll all horizontal and vertical seams. Field can be broomed or squeegeed in. Entire roof underlayment must be firmly pressed into roof deck to allow for proper “wetting in” of adhesive for maximum adhesion.
- At Pitches below 5/12: install at 4" horizontal lap line. 12" vertical overlap.
- At Pitches 5/12 and above install at either 2" or 4" horizontal lap line, 6-12" vertical overlap.
- Install subsequent courses in a shingling fashion.
- For steep pitches Sharkskin Ultra SA® can be installed vertically, in strapping application. When installed vertically, all vertical laps must be at 4" overlap line. All vertical laps must be firmly rolled in to the subsequent course to make sure there is a water tight seal. No wrinkles.
- Patch in holes and pipe flashings with Sharkskin Ultra SA®. Extend patch a minimum 6" beyond the hole or cut. Flash in all pipe flashing installed after primary installations in the same manner. Make sure patches are firmly rolled in to provide proper adhesion to the primary underlayment layer.

Kirsch Building Products LLC

Tel: (805) 750-0084

Fax: (805) 526-1116

1464 Madera Road #N, Suite 387 • Simi Valley, CA 93065

email: kirsch@sharkskin.us • www.sharkskin.us