



October 22, 2020

Re: Sharkskin Ultra SA® installation over fluted metal B-deck
Roof Deck: Metal B-Deck Installation:

1. Sharkskin Ultra SA® can be installed over metal B-Deck per the following installation details.
2. Metal B-deck must be free of dirt, debris and in a clean broom swept conditions.
3. Metal B-deck must be free of oil and contaminants.
4. Install Sharkskin Ultra SA® per the roll label "Installation and Instruction".
5. Care should be taken to position the Sharkskin Ultra SA over the metal B-deck prior to removing the release liner.
6. Once attached the Sharkskin Ultra SA should not be removed or re-positioned. Install a new sheet of Sharkskin Ultra SA if necessary.
7. Sharkskin Ultra SA should be lapped horizontally as to allow horizontal overlaps to terminate over the flat surface of the upper flute. This may require a greater overlap than the standard 2"-4" horizontal overlap called out in the installation instructions.
8. All horizontal laps must be rolled in using a heavy roller to provide consistent bonding across the entire horizontal lap.
9. All vertical laps must be overlapped as called out in the installation instructions or greater as field conditions may warrant. All vertical laps are to be rolled in using a hand roller to provide consistent bonding across the entire vertical lap.
10. Where a roll ends, or is terminated, a 6" x 48" 24 gauge termination strip must be screwed to the top of the metal flutes to provide the vertical end lap a solid attachment point.
11. Care should be taken not to step on or drop sharp objects over the unsupported areas of the metal B-Deck.
12. Repairs can be made using Sharkskin Ultra SA®.

Technical Department

Kirsch Building Products LLC

Tel: (805) 750-0084

Fax: (805) 526-1116

1464 Madera Road #N, Suite 387 • Simi Valley, CA 93065

email: kirsch@sharkskin.us • www.sharkskin.us